

BEDROCK

TRUCK BEDS



OWNER'S MANUAL

TABLE OF CONTENTS

- 2** Warranty and Registration Card
- 3** Welcome and Disclaimer
- 4** Maintenance Interval Chart
- 5 & 6** Installation Tips
- 7 & 8** Operator Tips
- 9 & 10** Wiring Harness Drawings

LIMITED WARRANTY

BEDROCK warrants all parts of its manufacture, furnished under this agreement, to be free from defects in workmanship and material for a period of 3 years or 36,000 miles from the date of purchase. The warranty card must be completed and mailed to BEDROCK or register online at www.bedrocktruckbeds.com within 30 days of install. This limited warranty covers the cost of the product. This limited warranty does not cover:

- 1) Installation
- 2) Labor
- 3) Freight
- 4) Normal Wear and Tear
- 5) Abuse
- 6) Damage Caused by Collision

This limited warranty is void if the product shows signs of alteration, modification, misuse, mishandling, improper care and/or neglect. Also, this limited warranty is void in the event of improper installation. The liability of BEDROCK under the warranty is limited, at BEDROCK's option, to repair or replace with equivalent products. This limited warranty is conditioned upon:

- a) BEDROCK being notified by purchaser within one month after discovery of any defects.
- b) The return of the defective product(s) to dealer within the limited warranty period.
- c) BEDROCK's examination of such product(s) and its satisfaction that such defects were not caused by negligence, misuse, improper maintenance, accident or unauthorized repair or alteration. The original limited warranty period of any product repaired or replaced by BEDROCK shall not thereby be extended.
- d) Return of warranty card or online warranty registration.

During the warranty period, this limited warranty is fully transferable, for so long as the warranty is in place.

CUT ALONG LINE AND MAIL

BEDROCK WARRANTY INFORMATION

Name: _____

Address: _____

Make/Model of Truck: _____

Serial Number of Bed: _____

Date Installed: _____

Installed By: _____

Mileage on Truck when Bed Installed: _____

P.O. BOX 667 | SHINER, TX 77984
361.401.7420 | BEDROCKTRUCKBEDS.COM



WELCOME AND DISCLAIMER

WELCOME TO THE BEDROCK TRUCK BEDS FAMILY

Thank you for purchasing your new BEDROCK truck bed. You have now joined a growing family with mammoth expectations for your truck bed. BEDROCK Truck Beds is a wholly owned subsidiary of Trailboss Equipment, LLC manufacturing under the name of "BEDROCK Truck Beds." Our beds are designed and manufactured to give you many years of reliable service. The combination of quality materials and top craftsmanship is what makes BEDROCK truck beds a step above the rest. In every design and manufacturing phase, the safety and comfort of your cargo is the highest priority. As a responsible truck bed owner, it should be your priority to be familiar with your new truck bed and to follow safety guidelines and the recommended maintenance instructions to ensure you have many years of safe hauling on the road. As you begin to use your new BEDROCK truck bed, this Owner's Manual will allow you to become more familiar with the operation, maintenance and care of your truck bed. The BEDROCK Truck Beds owner's manual will reference excerpts from other manufacturers' manuals which have components on BEDROCK's Truck Bed products.

DISCLAIMER

All truck beds manufactured by BEDROCK Truck Beds are designed to be used within the specific engineering guidelines. All truck beds should be used as designated by the manufacturer. BEDROCK Truck Beds reserves the right to make any change in paint, design or construction as necessary for engineering. All visual representations, specifications and guidelines are based on the latest product information available at the time of this publication. All truck bed models manufactured by Trailboss d.b.a. "BEDROCK Truck Beds" are covered in this publication.

For more information:

Call: 361-401-7420

Write: 959 State Hwy 95 N, Shiner, TX 77984

E-mail: sales@bedrocktruckbeds.com

Online: bedrocktruckbeds.com

MAINTENANCE

Maintenance Interval Chart

Notice: Refer to this chart for BEDROCK Truck Bed maintenance items only. Refer to vehicle maintenance schedule and the trailer schedule to maintain their necessary service items.

Interval	Component	Service Action
Every Use	Bed Deck	Clean deck of any loose objects before traveling
Every Month	Lights	Do a complete verification of light operation. Correct any issues found in your inspection
	Gooseneck Ball	Inspect ball for damage or flat spots and replace if necessary
		Apply thin coat of grease
Every Three Months	Spare Tire Storage (if equipped)	Check hardware tightness
	Storage Box Locks (if equipped)	Apply lock-lube in storage compartment locks
	Storage Box Hinges (if equipped)	Lightly lubricate the hinges and wipe off any excess
Every 5,000 Miles	Gooseneck Ball & Receiver Hitch	Inspect the gooseneck ball and receiver hitch to ensure they are secure

INSTALLATION TIPS

TRUCK BED INSTALLATION

- The truck bed is very heavy and must be safely elevated for installation. Never stand or lay underneath the truck bed while it is suspended in the air during installation. An accident involving the unexpected failure of lifting devices or lifting method will result in death or serious injury.
- Do not smoke when installing the fuel connection components. Ignition to the fuel vapors could ignite and result in death or serious injury.
- Fumes given off by batteries are combustible. Keep flame and sparks away. Do not store tools or metal objects near batteries. There is a risk of explosion if metal objects cause a short circuit. Sulfuric acid contained in batteries is poisonous. Do not allow acid to contact skin, clothing or your eyes. If you spill acid on yourself, immediately:
 - a) Flush your skin with water.
 - b) Apply a neutralizing agent such as lime.
 - c) Flush eyes with water for 10-15 minutes.
 - d) Immediately seek medical attention.
- Connect a ground strap between the truck bed and the truck chassis. Make sure the ground connection is not hindered by any painted surface.
- When all of the connections are complete, connect the negative cable to the negative battery terminal.
- Turn the ignition switch to the "ON" position (but do not start) and test the lighting system. Check the parking lights, brake lights, turn signals and clearance marker lights.

PRE-DEPARTURE INSPECTION

- If problems are found, first check that you have a proper ground between the bed and chassis by conducting a continuity test with a meter.
- Check the operation of all the hinged door latches and locks (if equipped). Lightly lubricate the hinges and wipe off any excess lube that would attract dust and dirt.
- Knowing the condition of your vehicle, truck bed and cargo is an important responsibility. A quick walk-around your vehicle can avoid many situations that could delay your arrival at your destination.
- Inspect the area in front of your vehicle and behind your vehicle to make sure there is no one standing, sitting or playing in those areas.
- Check the operation of the lights. Replace/repair any burned out lights before proceeding.
- If you are carrying any type of cargo on your truck bed, make sure it is tightly secured with chains or straps. It is always a

good idea to stop during the journey and check all cargo tiedowns.

- Clean off any loose dirt or debris from the truck bed deck.
- Clean any dirt, dust, mud or snow from the rear brake, turn signal and running light lenses. Make sure people behind you can see your lights clearly.
- Inspect tire condition and inflation on your vehicle and trailer per the recommendations of the truck and trailer manufacturer. Never drive with a known bad tire or one that is under inflated
- If towing a trailer, verify that safety chains, breakaway cable and light harness are connected properly.
- If equipped, make sure that all truck body doors and drawers are in their closed and latched position. Locking these doors is always a recommended practice.

instruction or serious injury can occur.

- The fuel filler location has been pre-determined to best suit the tank location on your vehicle.
- The diesel additive fill hole has a knockout that needs to be removed for diesel trucks requiring additive.
- Filler tube (not supplied by BEDROCK truck beds) should be routed to the fuel tank of your vehicle, per instructions supplied with filler tube.

FUEL FILLER ASSEMBLY INSTALLATION

- **Warning:** Installation requires cutting and grinding. Keep all ignition sources away when working with fuel tank filler pipe, or serious injury or death can occur.
- **Caution:** Fuel tank filler pipe must be installed according to vehicle requirements. Please read Owner's Manual. Follow fuel tank pipe manufacturer's

OPERATOR TIPS

OPTIONAL SPARE TIRE MOUNT

- Never leave a spare tire loose on the truck bed while moving the vehicle. A spare tire that falls on the roadway during travel could result in death or serious injury.
- Periodically check that your spare tire is securely attached to the mount with the correct necessary hardware.
- Contact BEDROCK for a spare tire mounting kit.

TRUCK BED STORAGE BOXES

- Some BEDROCK models include storage boxes that are secured with a hinged door. To prevent loss of storage box contents or damage to the door, close and lock the access doors before moving the vehicle.
- Every three months add a light coat of lubricating oil to the hinge. Wipe off any excess lube.
- Inspect the latch lock periodically. Lubricate the lock periodically to keep it from becoming tight. Wipe off any excess lubricant.
- Keep a spare key in the glove box of the vehicle. Lost keys can be replaced by contacting BEDROCK Headquarters.

PARTS

- Contact your local BEDROCK dealer with any parts inquiries. If they do not stock the part you

need, they can contact our factory for immediate shipment of your part.

- When inquiring about parts for your Bedrock truck bed, have the following information available:
 - a) Bed Model
 - b) Bed Serial Number
 - c) Quantity Required
 - d) Shipping Information

FEDERAL, STATE & LOCAL LAWS

Local municipalities and states may require special licenses or permits to operate this vehicle on public roads. These laws have been established to protect you and others. Contact your local motor vehicle administration for information. If you are transporting this vehicle across a state line, be knowledgeable of the laws of that state, and insurance regulations that are required in the state in which you are traveling. Refer to the Department of Transportation (DOT) regulations for documents regarding the necessary tie-downs required to secure your cargo.

OPERATOR SAFETY TRAINING TIPS

It is the responsibility of the operator driving this vehicle to be acquainted with the safe operating procedures for the vehicle they are driving. In addition to reading this manual, it is

important that the driver must read the vehicle's operation manual and trailer manual, and follow their recommendations.

- Avoid sharp, sudden steering actions that could cause the load to shift. Sudden loss of vehicle control could result in death or serious injury.
- Be aware of all pinch points on this truck body that could result in death or serious injury.
- Never allow passengers to be in or on the truck body when it is being moved. A loss of balance could result in death or serious injury.
- Never transport any quantities of dangerous, hazardous, flammable or poisonous materials in or on your vehicle unless stored in a proper container. Minor or serious injury could occur.
- Make sure all service body drawers, doors and latches are closed before driving this vehicle.
- Inspect the vehicle's lights for proper operation during your daily walk-around inspection. Federal law requires all vehicles to have tail lights, brake lights, side marker lights, turn signal, and side reflectors. Ensure all are present and in working condition.

to make sure that you have the right bed for the application. Then, using a spacer between the runners and the frame, position the bed so that the headache rack does not stick up over the cab of the truck more than 1 ½". There should be 2" of space between the cab and the headache rack on the bed.

Attach fastener on each side of the front, middle and rear; bolt to the frame, and then either bolt the fastener to your bed runners or weld them solidly. *

***NOTE:** Attachment components are not supplied with bed. Please use adequate material to fasten the frame and bed together. For any questions concerning materials or install kit, please contact BEDROCK.


***CAUTION:** Observe safety precautions when using welder on your vehicle. These are only recommendations and installation design is the responsibility of the installer. Follow vehicle manufacturer specifications when attaching plates to the truck frame.

EXPLANATION


Measure the width of the frame of the truck and the runners on the bed

WIRING HARNESS DRAWINGS

FRONT WIRING HARNESS GRANITE, DIAMOND AND SLATE SERIES



CENTER WIRING HARNESS GRANITE, DIAMOND AND SLATE SERIES





959 STATE HWY 95 N | SHINER, TX 77984
361.401.7420 | BEDROCKTRUCKBEDS.COM